

Electropolishing of Niobium SRF Cavities in Low Viscosity Aqueous Electrolytes without Hydrofluoric Acid



E. J. Taylor, T. Hall, S. Snyder, M. Inman, Faraday Technology, Inc., Clayton OH 45315, U.S.A.

A. Rowe, Fermilab, Batavia, IL 60510, U.S.A

Objective


- Develop eco-friendly electropolishing process for SRF cavities
- Reduce personnel and environmental risks

Conventional EP

- Nine parts sulfuric acid (95-98%) to one part hydrofluoric acid (49%)
- Jacquet "viscous salt film theory"
 - Thick viscous boundary layer focuses current on asperities under mass transport control
 - Hydrofluoric acid added to remove the surface oxide layer
- Diffusion limited access of fluoride to the surface

Approach

Pulse reverse waveform → Bipolar EP



Transition From Coupons to Single-cell Cavities

Waveform	V _{anodic} (V)	t _{anodic} (ms)	t _{off} (ms)	V _{cathodic} (V)	t _{cathodic} (ms)	H ₂ SO ₄ in Water (wt %)
Coupons:						
High Frequency - High Power	30	0.06	5.0	35	0.20	30
High Frequency - High Power	3	2.50	1.0	9	2.50	30
Cavities:						
Ultra Low Frequency - Low Power	4	200	300	10	200	5
Very Low Frequency - Low Power	4	100	150	10	100	10

Coupon Study:

Amelioration of Heat Build-up


(High Frequency / High Power Waveform)


t _{off} (ms)	Total Time (min)	Initial Temp. (°C)	Final Temp. (°C)
0.3	40	15	33
0.6	120	14	35
1.0	120	14	28
5.0	560	16	19

- 3"x 3" Coupons
- 30 wt% H₂SO₄ in water
- 15 L bath volume

Anodic Current Transition → "Cathodic Polishing"

(Low Frequency/Low Power Waveform)






Anodic pulse: Niobium oxide film growth followed by oxygen evolution Cathodic pulse: Niobium oxide removal


→ The anodic current transition correlates with niobium polishing

Simulation of Electrode to Cavity and Area Ratio

Variable gap; cathode to cavity surface (~1 to 3.5")
Variable area ratio; cavity to cathode surface area ratio (~2:1 to 5:1)
In order to maintain the anodic current transition:

- → As coupon gap increases; waveform frequency decreases
- → As coupon surface area ratio decreases; waveform frequency decreases





Developmental Cavity (TE1NR001)

- Initial processing similar to conventional cavity EP
 - Horizontal orientation
 - Rotation
 - 60% volume fill
 - → Based on visual inspection, no polishing
- Horizontal cavity orientation developed for viscous electrolyte
 - Avoid streaking due to bubbles
 - Rotation rate optimized to form "electrolyte film"
 - → Conditions not appropriate for low viscosity electrolyte
- Subsequent processing
 - Vertical orientation
 - No rotation
 - 100% volume fill
 - → Based on visual inspection, polishing; confirmed at Fermilab

Performance Cavity Experiment 1 (TE1DESYB5)

- Vertical orientation
- No rotation
- 100% volume fill
 - 5 wt% H₂SO₄ in water; 4 V anodic for 200 ms: off for 300 ms:
 - 10 V cathodic for 200 ms
 - − Average ~30 µm removed
 - → Cavity performed with a quench field about 31 MV/m with a low-field Q₀ of 2.0E+10 which is within the normal performance band of a cavity receiving standard EP.

Performance Cavity Experiment 2 (TE1AES007)

- Vertical orientation
- No rotation
- 100% volume fill
 - 5 wt% H₂SO₄ in water; 4 V anodic for 200 ms: off for 300 ms: 10 V cathodic for 200 ms
 - Average ~30 µm removed, followed by
 - 10 wt% H₂SO₄ in water; 4 V anodic for 100 ms: off for 150 ms: 10 V cathodic for 100 ms
 - − Average ~70 µm removed
 - → The cavity exhibited "average" performance as well as Q-disease, which was eliminated after bake.

Performance Cavity Experiment 3 (TE1AES007)

- Vertical orientation
- No rotation
- 100% volume fill
 - 10 wt% H₂SO₄ in water; 4 V anodic for 100 ms: off for 150 ms: 10 V cathodic for 100 ms
 - Average ~20 µm removed
 - → The cavity did not exhibit Q-disease.

Performance Cavity Experiment 4 (TE1AES012)

- Vertical orientation
- No rotation
- 100% volume fill
 - 10 wt% H₂SO₄ in water; 4 V anodic for 100 ms: off for 150 ms: 10 V cathodic for 100 ms
 - − Average ~25 µm removed

EP in the same electrolyte

→ The cavity achieved a maximum gradient of ~44MV/m with a Q of 1x1010, the highest gradient and Q value at this gradient observed at Fermilab in any cavity regardless of processing technique.

Summary

- Bipolar EP successfully transitioned from coupons to single cell SRF cavities
- Pulse reverse waveforms enable sulfuric acid-water electrolytes WITHOUT HF
- Vertical orientation cavity enables without rotation
 - Lower cost industrial implementation
 Simultaneous multiple cavity processing
- Potential for sequentially applied waveforms tuned for bulk removal followed by final

